

Index**A**

Add New Distance Light 652, 800
 Add New Spotlight 682, 698
 Aligned 630
 Angular 623
 Annotate Tab 648, 707, 760
 Annotation(s) 604, 647-650, 685-686, 700-720
 Annotation Feature Dialog 714-719
 Annotation Features 705-720
 Annotation Orientation 720
 Annotations Off 702
 Appearance Gallery 692, 769
 Arc 637-641
 ASME 647, 684, 705
 Assembly 583, 607, 764
 Attributes 652
 Axes (drawing) 649

B

Background Color 758
 Bill of Materials 627
 Blend(s) 629-643
 Blend Options 630
 Blend Sections 630-632

C

Centerline 601, 637, 639
 Chamfer(s) 667
 Change Focus 799
 Child 686
 Children 723
 Circle 643, 670, 691
 Close Window 682
 Coaxial 780-781
 Coaxial Hole 780-781
 Coincident 609, 623
 Color Edit(or) 682, 751-753, 798
 Color for Lighting 682, 751, 798, 800
 Configuration File(s) 765
 Constraint(s) 708
 Counterbore 610, 618, 676
 Create an entity 773
 Create Driving Dimension AE 707
 Create Surface Feature 715
 Customize Ribbon 765

D

Datum Plane(s) 588, 785
 Default Constraint 607
 Default Shell Thickness 722
 Define Internal Sketch 587, 601
 Delete 599, 622
 Delete Old Versions 684
 Diameter 620
 Diameter Dimension 638

Dimension Properties 604, 710
 Dimension tab 589
 Distance 607
 Distance Light 752, 800
 Draft 732, 763-764, 779, 781
 Draft Angle 763-764
 Draft Features 763
 Draft Hinges 732, 764, 775, 779, 781
 Draft References 732
 Draft Surfaces 764
 Draft Tool 764
 Drag Handle 738, 744, 774
 Drag tool 617-618, 805-806
 Drill 736
 Drill to intersect 737

E

Edit 678
 Edit Definition 621
 Edit Internal Sketch 778
 Enhanced Realism 754
 Excluded Surfaces 722
 Exit Orient Mode 794

F

Flexible Modeling 805
 Flip Material Side 694
 Format(s) 615, 647, 804
 Front Datum Plane 587
 Fully Constrained 619

G

General Blends 630
 Geometric Tolerances 685
 Geometric Tolerancing 785
 Geometry Check 796
 Geometry Tolerances 785
 Graphics Window 703, 722, 763
 Grid 636-669
 Grid Spacing 636
 Ground Ends 685, 687, 693, 696
 Group 721, 725, 782-783, 787
 Grouped Features 783

H

Helical Sweep 685-689
 Hidden Line 636
 Hole Pattern 571, 591, 644, 692, 721
 Hole Shape 590, 602
 Hole Tool 590, 643
 Holes 743
 Hook Ends 797, 792
 Hyperlink 703
 Hyperlink ScreenTip 703

I

Import customization file 601
 Import/Export 601, 765

Inner Faces 651
 Insert Here 746, 748-749
 Insert Mode 723-724
 Inserting Features 723

L

Layout Tab 760, 804
 Length 614
 Lights 682, 751, 798-799
 Loop 593, 674, 693

M

Material(s) 633, 653, 688, 729
 Merge Ends 652
 Mirror Plane 783
 Mirrored 783
 ModelCHECK 796
 Model Notes 685, 686, 700
 Model Properties 587
 Model Tree 621, 702, 740
 Model Tree Items 687
 Modify Dimensions 790
 Move with Dragger 805-806

N

New Constraint 608-609
 No In Fcs 652
 Note 685-687

O

Offset 588, 593, 607, 730, 734
 Offset Datum 588, 772
 Offset References 738-739
 Offset References Collector 738-739
 Old Versions 599, 694, 733
 Open URL 704
 Options 583, 630, 636, 647, 679, 685
 Orient Mode 794
 Orient Tab 706

P

Parallel Blends 629-631
 Parallelism 712
 Pattern(s) 583, 589, 644
 Pattern (axial) 672-673
 Pattern (components) 583, 591, 593
 Pattern (dimensional) 583, 589, 677
 Pattern (direction) 583, 591, 603, 676
 Pattern (fill) 583, 593-594
 Pattern Group 625-626
 Pattern (reference) 583, 611, 620
 Pattern Table 740-742
 Pattern Tool 583
 PDF U3D 755-758
 Perspective 758
 Place Gtol 713
 Place Manually 622
 Placement tab 610, 772

Point(s) 637, 669
 Polar Grid 635-636, 669
 Previewed Pattern 643
 Primary Tab 713
 Pull Direction 764
 pvc.mtl 633

Q

Quick Reference Cards 583, 629

R

Radial 636
 Reference (Pattern) 583, 611
 Reference Viewer 627
 References 659, 722, 775
 References tab 733, 770, 775
 Regenerate 794
 Regenerates Model 794
 Removed Surfaces 722, 733
 Rename 633, 729
 Render 682, 750, 797, 803
 Render Setup 750, 797
 Render Window 803
 Reorder 721-723, 744-746
 Reordering Features 723, 746
 Resume(s) 661, 725, 761-764, 792
 Reverse Pull Direction 775
 Rib 589
 Ribbon 601, 663, 760, 765
 Room 763, 801-802
 Room Appearance Editor 801-802
 Rotate 663
 Rotational Blends 620
 Round Edges 744, 793
 Round Tool 747

S

Save 559
 Save a Copy 696, 755
 Scene(s) 682, 751-753, 763, 798
 Screen Tip 703
 Section Sweep 651
 Set Datum 633, 708
 Sets 597, 784
 Settings 742, 787
 Shade 727
 Shape Tab 602, 677, 739
 Shell 629, 645, 721-722, 733, 770
 Shell Thickness 722, 745
 Shell Tool 629, 721-722, 733, 770
 Show Model Annotations 647, 660, 707
 Sketch 659
 Sketch Sec 630, 636
 Sketch Traj 652
 Sketcher 636, 640, 652, 669-670
 Sketcher Point 669
 Spline 630
 Split Areas 664

Spot Light 751, 798-799
 Start Point(s) 637-639, 789
 Start the View Manager 686
 Suppress 763-764, 787-788, 791-792
 Suppressed Features 723, 747, 763-764, 787-788, 792
 Surface Finish 686, 715-719
 Sweep 651-652, 665, 685-688, 699
 Sweep Section 651, 662
 Sweep Tool 689, 699
 Swept Blend 629

T

Temporary Shade 628, 793
 Text Style 701, 789
 Text Extrusions 763, 787, 791-795
 To Selected 671, 774, 776, 780
 Toggle Section 639, 641
 Tools tab 627
 Top Datum 601
 Trajectory 651-652, 659-661, 685

U

Units Change 587
 Units Manager 765
 URL 685, 703-704
 Use Perspective Projection 758

V

Variable Text Tab 718
 Velocity 794
 View Manager 706, 710, 786
 Visibility 786

W

Welding 595-599
 Weldments 583-586
 Working Directory 615, 765